


Woodpeckers®


INSERT TEMPLATE

O W N E R ' S M A N U A L



You Will Need

- Jig Saw
- Router Bit



If you think you're missing anything, email us at mailroom@woodpeck.com.
You can also call us at 800-752-0725 from 9:00 a.m. to 5:00 p.m. EST Monday - Friday.

Woodpeckers®


PRECISION WOODWORKING TOOLS

Woodpeckers, LLC Strongsville, Ohio · woodpeck.com

© 2020 Woodpeckers, LLC

California Proposition 65 WARNING: This product may contain one or more chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

Figure A



1. Layout the location of the router plate opening. Draw a 9-1/4" x 11-3/4" rectangle.

2. Position the Insert Template over the rectangle and clamp in place. Keep the clamps as close to the ends of the template as possible to allow room for the router.

Figure A

3. Set your router bit (pattern type with bearing on shank as shown) to protrude slightly more than 3/8" (.400" to be exact).

4. Route a groove all the way around the inside edge of the template. It is easier to make multiple shallow passes. Make sure to make a couple clean up passes to ensure all the stock has been removed.

5. Use a jig saw to cut out around the inside edge of the island to leave a 1/2" wide lip for the plate to rest on.

6. Use a chamfer bit, file or sand paper to clean up the top inside edge. This is particularly beneficial if your table is laminated.

Figure B




Figure C

