


Woodpeckers® CLAMP RACK-IT®SYSTEM

O W N E R 'S M A N U A L

Woodpeckers Clamp Rack-It System is a fully adjustable, expandable space saving solution for storing all of your woodworking clamps. The incremental spacing and two tiered arms enable you to configure the system to fit your clamp storage needs, regardless of size, style, or number.







| | CRIS-6A | CRIS-6B | CRIS-6C | CRIS-16 | CRIS-24 | CRIS-32 |
|-------------------------------------|---------|---------|---------|---------|---------|---------|
| A. Backer Plate | 1 (6") | 1 (6") | 1 (6") | 1 (16") | 1 (24") | 1 (32") |
| B. Large Arm Set* Left & Right Side | 1 | 2 | Х | 3 | 3 | 3 |
| C. Small Arm Set* Left & Right Side | 1 | Χ | 2 | 2 | 2 | 2 |
| 1/4" x 1-3/4" Lag Bolts | 2 | 2 | 2 | 4 | 4 | 6 |
| 1/4" Washers | 2 | 2 | 2 | 4 | 4 | 6 |

*(4) 10-32 x 3/8 Thread-Forming Screws are included with each Arm Set

INSTALLING A SINGLE CLAMP RACK-IT SYSTEM BACKER PLATE

1. Find the location for the Clamp Rack-It Backer Plate on your wall. The Backer Plate must be located where the Lag Bolts will be securely fastened to a stud or wood wall.

WARNING! It is not recommended to install directly into drywall or lower strength wall types.


2. Drill pilot holes for top left and right Lag Bolts (center position for the 6" Backer Plate). **Ensure they are level.** Use the chart to the right to set the spacing.

NOTE: If installing multiple Backer Plates, refer to page 3 "INSTALLING CLAMP RACK-IT SYSTEM MULTIPLE BACKER PLATES" instructions.

FIGURE A


| | 7.0071271 | | | | | | | |
|--|--------------------------|--------------------|------------------|--|--|--|--|--|
| | PILOT HOLE SPACING CHART | Lag Bolt | Lag Bolt | | | | | |
| | | Horizontal Spacing | Vertical Spacing | | | | | |
| | 6" Backer Plate | N/A | 7-3/16" | | | | | |
| | 16" Backer Plate | 15-3/4" | 7-3/16" | | | | | |
| | 24" Backer Plate | 23-3/4" | 7-3/16" | | | | | |
| | 32" Backer Plate | 31-3/4" | 7-3/16" | | | | | |

FIGURE B



INSTALLING CLAMP RACK-IT SYSTEM MULTIPLE BACKER PLATES

The Clamp Rack-It System Backer Plates are designed to work as stand alone or inline mounting. When mounting the Backer Plates inline, the spacing will be a bit different than stand alone. Determine the central hole location, then measure out from that hole. FIGURE C



1. Find the location for the Clamp Rack-It Backer Plate on your wall. The Backer Plate must be located where the Lag Bolts will be securely fastened to a stud or wood wall

WARNING! It is not recommended to install directly into drywall or lower strength wall types.

32" Backer Plate

EICLIDE D

2. Drill pilot holes for top left and right Lag Bolts. Ensure they are level. Use the chart to the right to set the spacing for multiple Backer Plates. FIGURE D.

Follow Steps 3-8 on page 2 to continue installation.

| FIGURE D | | | | | | | | |
|----------|--------------------------|--------------------|------------------|--|--|--|--|--|
| | MULTIPLE BACKER PLATE | Lag Bolt | Lag Bolt | | | | | |
| | PILOT HOLE SPACING CHART | Horizontal Spacing | Vertical Spacing | | | | | |
| | 16" Backer Plate | 15-7/8" | 7-3/16" | | | | | |
| | 24" Backer Plate | 23-7/8" | 7-3/16" | | | | | |
| | | | | | | | | |

31-7/8"

7-3/16"


There are no provisions for installing multiple 6" Backer Plates in-line.

INSTALLING THE ARMS OF THE CLAMP RACK-IT SYSTEM


Installation is the same for both the Large and Small Arm Sets. Measure the width of the bar on your clamp. This will determine the amount of space that is necessary

between the left and right Arms to fit your clamps.

- 1. Identify the Left and the Right Arm of each Arm Set. The lip of the Arms should both face outward to form the rack. FIGURE E
- 2. With the location determined. install the Thread-Forming Screws for one Arm into the top and bottom positions of the Backer Plate. Leave at least an 1/8" gap between the plate and the screw head.



- 3. Slot the bottom opening of the left Arm around the lower Thread-Forming Screw, then slide the offset keyhole slot over the top Thread-Forming Screw. FIGURE F
- 4. Slide the left Arm down so the top of the keyhole slot is resting on the Thread-Forming Screw.
- 5. Tighten the two Thread-Forming Screws.
- 6. Leaving the width of your bar clamp in between the left and the right Arm, install the right Arm.



Woodpeckers®

PRECISION WOODWORKING TOOLS Woodpeckers, LLC Strongsville, Ohio · **woodpeck.com** © 2019 Woodpeckers, LLC

